

Gode råd ved opklæbning af FrasterFilt på vægge eller andre emner

1. Filten skal være tilpasset væggen/ emnet inden fastklæbning.

Det flotteste resultat opnås ved omhyggelig opmåling af væggen og udskæring af filt på skærebord med digital kniv. En efterfølgende og nødvendig tilpasning af filten foretages ved skæring i filtlen med en skarp kniv efter lineal og i et ubrudt snit på en plan flade. Det anbefales ikke at skære filtlen efter montering på væggen.

2. Lim påføres væggen i et jævnt lag med rulle, spartel og/eller pensel.

Vær opmærksom på limens åbningstid. Tørrer limen op inden filtlen sættes på, forringes limens klæbeevne. En vandbaseret gulvlim som feks Uzin 2000S eller Danattack vinyl 246 fra Danalim kan anvendes.

3. Filten monteres i den våde lim på væggen.

Vær opmærksom på, at filtlen ved montering kan bearbejdes, således at den både kan "krympes" og strækkes.

Er filtlen lidt for stor i forhold til væggen, kan man med fordel ved opsætning "krympe" den fremfor at skulle skære et stykke af. "Krympning" skal i denne henseende forstås som en sammentrækning / sammenskubning af filtlen på et par procent.

4. Umiddelbart efter opsætning rulles væggen med en "trykrulle" således at filtlen hæfter jævnt på hele fladen.

Opklæbning med dobbelt klæbende tape.

Fraster kan levere filt med +Stick&Peel, som er en dobbelt klæbende tissue tape med modificeret vandbaseret acrylklæber med silikoniseret papir. Tapen har en høj klæbekraft på de fleste typer overflader. Tapen har høj modstand overfor fugt og temperatur svingninger, når den er monteret. Overfladen hvor tapen monteres skal være ren, tør og fri for fedt og olie. Emnerne skal så vidt muligt have samme temperatur. Det anbefales at rengøre med isopropyl-alkohol før montering. Tapen skal påføres med tryk.

Ovenstående er råd opnået på baggrund af praktisk erfaring. Fraster kan ikke gøres ansvarlig for følgerne ved at følge disse råd. Ved en hver tvivl anbefales det at kontakte og lade monteringen udføre af en professionel montør.

Tips on gluing FrasterFelt to walls or other surfaces

1. The felt should be adapted to fit the wall/surface before gluing it on.

The best result is achieved by carefully measuring the wall and cutting the felt on the cutting table with a digital knife. Any necessary subsequent adjustment of the felt shall be made by cutting the felt with a sharp knife and a ruler in one unbroken cut on a flat surface. It is not recommended to cut the felt after it has been fixed to the wall.

2. Glue is applied to the wall in one even layer with a roller, a spatula and/or a brush.

Be aware of how long the glue keeps its adhesive properties after it has been applied. If the glue dries up before the felt is put on, its adhesiveness deteriorates. A water based floor adhesive such as Uzin 2000S or Danattack vinyl 246 from Danalim may be used.

3. The felt is placed on the wet glue on the wall.

Please keep in mind that the felt can be manipulated during application, so that it can be either "shrunk" or stretched.

If the felt a little too large for the wall, during application to the wall, one may prefer to "shrink" it instead of having to cut off a piece. "Shrinking" in this context means to contract/push together the felt by a few percent.

4. Immediately after application, the wall is rolled over with a "rolling pin" so that the felt sticks evenly over the whole surface.

Gluing with double-sided tape.

Fraster supplies felt with +Stick&Peel, a double sided tape which consists of a tissue carrier coated on both sides with a modified acrylic dispersion adhesive. It has excellent adhesion properties. It has very good resistance to ageing, climate and temperature.

All substrates should be clean and contamination free, a solvent such as isopropyl-alcohol is recommended for cleaning purposes, and the tape should be applied with pressure.

The above advice is obtained on the basis of practical experience. Fraster can not be held responsible for any consequences caused by following these tips. If in any doubt, we recommend you to have the work done by a qualified professional.